



Use a high quality 3/4" plywood or high quality MDF. Round off all corners for ports as much as possible. If using screws make sure to pre-drill and use tite bond wood glue or similar. I suggest using a brace in the middle of each enclosure from top to bottom and side to side.